

Back Seat Removal

Republished from <http://www.bullittarchive.com/>

Easiest way to remove the back seat is take the seat belt buckle and insert it between the bottom of the seat and the carpeted floor. Try to hold the buckle parallel to the ground and NOT at an angle. Insert it about 8 inches from the door seal and then slide it towards the center of the seat.

You will hit the side of the catch mechanism. Pull the buckle back slightly and move it about an inch further. Push the buckle in and it will release the catch.



Same procedure for the other side of the seat. You can now lift the back seat up.

